



Education and Culture DG

Lifelong Learning Programme



Please note that on page 15 in the booklet "Securing cargo for goods by road in accordance with EN 12195-1:2010" the tables are only valid for an angle between platform and the webbing below 60°.

The valid tilt table for loop lashing on page 15 is as follows:

H/B	1 row	2 rows	3 rows	4 rows	5 rows
0,6	no tip	no tip	no tip	6,5	4,1
0,8	no tip	no tip	5,6	3,1	2,3
1,0	no tip	no tip	3,1	2,0	1,6
1,2	no tip	4,6	2,1	1,5	1,3
1,4	no tip	3,0	1,6	1,2	1,0
1,6	no tip	2,2	1,3	1,0	0,86
1,8	no tip	1,8	1,1	0,86	0,74
2,0	no tip	1,5	0,94	0,75	0,65
2,2	5,1	1,2	0,83	0,67	0,58
2,4	3,7	1,1	0,74	0,60	0,53
2,6	2,9	0,96	0,66	0,54	0,48
2,8	2,4	0,86	0,61	0,50	0,44
3,0	2,0	0,78	0,56	0,46	0,41
3,2	1,8	0,72	0,51	0,43	0,38

Sorry for any possible inconvenience caused by the printing mistake.